TUB INSTRUCTION

First time, if unpacked in water, please warm up the tub in warm water first, then carefully open tub;
Just inflate 80-90% is enough, water will heat the air to make air inflate;
Make sure hot water mix with cold water directly, if hot water flows on PVC or gas valve hot water may damage pvc or gas valve;
First time, pump water two hours later after it is inflated;
Place on a even clean surface, no sharp stuff left on the surface
Inflate according to drawing on box;
Double check all air valves, side outlet and floor outlet are tight
Always pump cold water first;
Max water temperature 45o C;
Do not use high-pressure pump/compressor to inflate;
Do not leave children unattended;
This is not a lifesaving device;
The plastic hose: put the bigger end into grate drain;
Connect the other end of plastic hose with the water outlet carefully, if too tight please warm up hose by warm water